


Pulsar Parts & Accessories








PULSAR 4 PARTS


Diagram Number	Part Number	Description
1	**93-71879**	Lid for Pulsar 4 Feeder
2	**93-71880**	Shut Off Assembly for Pulsar 4
3	**93-71881**	Briquette Screen Assembly for Pulsar 4
4	**93-71882**	Screw for Pulsar 4 Lid
5	**93-71883**	Hinge Rod for Pulsar 4 Lid
6	**93-71884**	Pulsar 4 Hopper
7	**93-71885**	Hex Nut Plastic Screw, 1/4"-20x5/8"
8	**93-71886**	Mounting Plate for Spray Tree
11	**93-71889**	Lid Switch
18	**93-71896**	Electronic Shut Off
19	**93-71897**	Deflection Plate
23	**11-060**	Poly Tubing, 3/8", per foot
25	**93-79217**	Discharge Valve Sub-Assembly
26	**93-71903**	Discharge Tank
27	**93-71904**	Washdown Mounting Plate
30	**93-71898**	Parker Fitting (W8ME8)
33	**93-71535**	Emer. Shut Off Valve with Arm
34	**93-71536**	Emer. Shut Off Mounting Plate
35	**93-71910**	Rubber Gasket for Emergency Shut Off Valve
36	**93-71749**	Plastic Screws (1/4-20) 3 1/4" for ESV (for Pulsar 4 only)
37	**93-71539**	Emer. Shut Off Float Plate
38	**93-71538**	Emer. Shut Off Float Plate PVC/Discharge Arm Nut
39	**93-71540**	Emer. Shut Off Overflow Float
40	**93-79810**	Discharge Valve Float
41	**93-79806**	Discharge Valve Body
43	**93-79805**	Discharge Valve Arm
50	**93-71918**	Parker Fitting (W10MC8)
64	**11-068**	Poly Tubing, 5/8", per foot
68	**93-75860**	8 - 32x5/8" PVC Screws (4)
73	**93-72863**	Discharge Valve Enh. Adaptor
74	**93-79218**	Check Valve (True Union)
77	**93-71576**	Discharge Valve Gasket - P4
--	**93-79804**	Discharge Valve Assembly

PULSAR SYSTEM ACCESSORIES

Part Number	Description
8-011	Pulsar Venturi, 1" (P3)
8-012	Pulsar Venturi, 1 1/2" (P4 + P3)
8-013	Pulsar Venturi, 2"
93-79214	Pulsar 1 HP Booster Pump, (P4 + P3)
11-060	Poly Tubing, 3/8", per foot
11-065	Poly Tubing, 1/2", per foot
11-068	Poly Tubing, 5/8", per foot
93-71894	Pulsar Solenoid Valve, 1/2", 24V (P4 + P3)
8-040	Pulsar Plus Acid Cleaner, quart
49-057	Chemical Scoop

NOTE: The most commonly used parts are listed here. Inquire for additional parts you require or visit our website.





PULSAR 3 PARTS

Diagram Number	Part Number	Description
1	**93-71608**	Hinge Rod w/Set Screw for P3 Hopper
2	**93-71607**	Lid for P3
3	**93-71609**	Briquette Screen Assembly P3
4	**93-71606**	Hopper without Lid for P3
5	**93-71619**	Elbow (W6ME6) 3/8" for Feeders 30991 & P3
6	**93-71617**	Spray Nozzle for P3
7	**93-79047**	Manifold for P3
8	**93-71620**	Deflection Plate Assembly
9	**93-71610**	Base without Assembled Parts for P3
10	**93-79806**	Discharge Valve Body
11	**93-71536**	Emergency Shut Off Mounting Plate
12	**93-71535**	Emergency Shut Off Valve with Arm Only
13	**93-71537**	Emergency Shut Off Mounting PVC Screws (1/4-20x4)
14	**93-71539**	Emer. Shut Off Float Plate
15	**93-71538**	Emer. Shut Off Float Plate PVC Nut/Dischrge Arm Nut
16	**93-71540**	Emer. Shut Off Ovrflow Float
17	**93-71496**	Emer. Shut Off Valve Assembly - part 71910 not included
18	**93-71583**	Discharge Valve Locknut
19	**93-71613**	(4026) O-ring #115-used in plug
20	**93-71612**	Plug for Feeder Body for P3
22	**93-79805**	Discharge Valve Arm
23	**93-79810**	Discharge Valve Float
24	**93-71614**	Tube Connector(P8MC4) P3
25	**93-71621**	1/2" Ball Valve MM (inlet)
26	**11-065**	Poly Tubing, 1/2", per foot
27	**93-71627**	1/2" Ball Valve MF (outlet)
28	**93-71588**	(5008) 1/2"x1/2" Female Connector (P8FC8)
29	**93-71611**	1/2" x PVC Nipple
30	**93-71910**	Rubber Gasket for Emergency Shut Off Valve
37	**93-72864**	P3 Enhancement Kit
38	**93-79217**	Discharge Valve Sub-Assy.
--	**93-79804**	Discharge Valve Assembly